FEED ADJUSTMENT INSTRUCTIONS

1. Find the feed adjustment value under which the distance between the horizontal lines is exactly 200 mm,
2. Pay attention to align the ruler to the vertical guideline during the measurement
3. If you don't have an accurate ruler, cut off the measuring tool on the right, and use that instead of a ruler
4. Enter the found value into the wizard



